



INFORMATICS INSTITUE OF TECHNOLOGY DEPARTMENT OF COMPUTING

Module: 5COSC009C.2

Software Development Group Project

Module Leader: Mr. Guhanathan Poravi

Paddy Weed Detector

Team Hypesters		
Name	lit ID	UoW ID
Akila Nanayakkara	2018400	w1742308
Kisal Wedage	2018368	w1742101
Moveen Wijerathne	2018541	w1742328
Amilakelum Kodikara	2018395	w1742107
Danushka Samarakoon	2018382	w1742106
Malshama Perera	2018446	w1742313

Contents

*	Data Science Model Code	3
•	Data Set Importing and Pre-Processing	3
•	Training the CNN Data Science Model	5
•	Testing the Data Science Model in the Console	7

Data Science Model Code

Data Set Importing and Pre-Processing

```
import numpy as np
import matplotlib.pyplot as plt
import cv2
from tqdm import tqdm
import os
os.environ['TF_CPP_MIN_LOG_LEVEL'] = '2'
DATA DIRECTORY = "D:\iit\year-2\SDGP\weed-
detector\paddyWeedDetector\Data_set\datatrain" #path where the data set is
Located
CATEGORIES = ["paddy", "weed"]
for category in CATEGORIES:
   path = os.path.join(DATA DIRECTORY, category) # create path to paddy and
weed
    for img in os.listdir(path): # iterate over each image per paddy and weed
        gray img array = cv2.imread(os.path.join(path, img),
cv2.IMREAD_GRAYSCALE) # convert to array and gray scaling
       plt.imshow(gray_img_array, cmap='gray') # graph it
       plt.show() # display
       break # to display one picture in gray scale
   break
print(gray img array)
print(gray_img_array.shape)
IMAGE SIZE = 50 #resizing images to 50 by 50
resize img array = cv2.resize(gray img array, (IMAGE SIZE, IMAGE SIZE))
#adding the resized images to an array
plt.imshow(resize_img_array, cmap='gray')
plt.show()
training data array = [] #training data array
def create training data():
    for category in CATEGORIES:
       path = os.path.join(DATA DIRECTORY, category) # create path to paddy
and weed
        class_num = CATEGORIES.index(category) # get the classification (0
or a 1). 0=paddy 1=weed
       for image in tqdm(os.listdir(path)): # iterate over each image per
paddy and weed
                image array = cv2.imread(os.path.join(path, image),
```

```
cv2.IMREAD GRAYSCALE) # convert to array
                image_array_2 = cv2.resize(image_array, (IMAGE_SIZE,
IMAGE SIZE)) # resize to normalize data size
                training_data_array.append([image_array_2, class_num]) # add
this to training_data
            except Exception as e: #to keep the output clean...
                pass
create training data()
print(len(training data array))
import random
#to balance the training data input to the model
random.shuffle(training_data_array) #this will suffle the data and input to
the modle.
for sample in training_data_array[:10]: #checking if the shuffling is working
    print(sample[1])
#making the modle (pickles)
X = []
y = []
for features, label in training data array: #packeting the shuffled data to
arravs
    X.append(features)
    y.append(label)
print(X[0].reshape(-1, IMAGE_SIZE, IMAGE_SIZE, 1))
X = np.array(X).reshape(-1, IMAGE_SIZE, IMAGE_SIZE, 1)
y = np.array(y)
import pickle #saving the processed data inside a pickle
pickle_out = open("X.pickle","wb")
pickle.dump(X, pickle_out)
pickle_out.close()
pickle_out = open("y.pickle","wb")
pickle.dump(y, pickle_out)
pickle out.close()
```

Training the CNN Data Science Model

```
import tensorflow as tf
from tensorflow.keras.models import Sequential
from tensorflow.keras.layers import Dense, Dropout, Activation, Flatten
from tensorflow.keras.layers import Conv2D, MaxPooling2D
from tensorflow.keras.callbacks import TensorBoard
import pickle
import time
import os
os.environ['TF CPP MIN LOG LEVEL'] = '2'
gpu_options = tf.GPUOptions(per_process_gpu_memory_fraction=0.333)
sess = tf.Session(config=tf.ConfigProto(gpu options=gpu options))
#importing the pickles we create
pickle in = open("X.pickle", "rb")
X = pickle.load(pickle in)
pickle_in = open("y.pickle", "rb")
y = pickle.load(pickle in)
X = X/255.0 #normalizing the data by scailing, min is 0 and max is 255
dense layers = [2]
layer_sizes = [64, 128]
conv_layers = [3]
for dense layer in dense layers:
    for layer size in layer sizes:
        for conv layer in conv layers:
            NAME = "paddyweedCNN-{}-conv-{}-nodes-{}-dense-
{}".format(conv_layer, layer_size, dense_layer, int(time.time()))
            tensorboard = TensorBoard(log dir='logs\ {}'.format(NAME))
            print(NAME)
            # training the model
            model = Sequential()
            model.add(Conv2D(layer_size, (3, 3), input_shape=X.shape[1:])) #
Convolutional layer
            model.add(Activation('relu')) # activation layer
            model.add(MaxPooling2D(pool_size=(2, 2))) # max pooling layer
            for 1 in range(conv layer - 1):
                model.add(Conv2D(layer_size, (3, 3)))
                model.add(Activation('relu'))
                model.add(MaxPooling2D(pool size=(2, 2)))
            model.add(Flatten()) # this converts our 3D feature maps to 1D
feature vectors
            for 1 in range(dense layer):
                model.add(Dense(512)) # dense Layer
```

Testing the Data Science Model in the Console

```
import os
os.environ['TF_CPP_MIN_LOG_LEVEL'] = '2'
import cv2
import tensorflow as tf
CATEGORIES = ["paddy", "weed"] # will use this to convert prediction num to
string value
def prepare(filepath):
    IMAGE_SIZE = 50 # 50 in txt-based
    image grayscale array = cv2.imread(filepath, cv2.IMREAD GRAYSCALE) # read
in the image, convert to grayscale
    image_resize_array = cv2.resize(image_grayscale_array, (IMAGE_SIZE,
IMAGE SIZE)) # resize image to match model's expected sizing
    return image_resize_array.reshape(-1, IMAGE_SIZE, IMAGE_SIZE, 1) # return
the image with shaping that TF wants.
model = tf.keras.models.load model("paddyWeedDetectorModelWithArch.h5")
prediction = model.predict([prepare('African-Lovegrass-
BuckleyEcologyLab.jpeg')]) # PASSING A LIST OF THINGS YOU WISH TO PREDICT
print(CATEGORIES[int(prediction[0][0])])
```